



Pells ONE

Balance Bike Pells One



Congratulations on your purchase of the Pells One balance bike.
A balance bike is designed to help children to learn the basic techniques needed to ride a single-track vehicle.

Please follow these instructions when assembling the bike.

If you do not follow these instructions, the bike may not work properly and your child may fall or be injured!

For more information and a video tutorial, please visit www.pells.eu/en/instruction-for-use/

Contents of package

- Frame with rear wheel
- Front wheel
- Saddle
- Seatpost clamp
- Handlebar
- Stem faceplate
- 4 x handlebar mounting bolts
- 2 x nut lock washers
- Allen key 4
- Allen key 5




- EN Instructions
- DE Anleitung
- FR Mode d'emploi
- ES Instrucciones
- I Istruzioni
- HU Utasítás
- PL Instrukcje
- CZ Návod na použití
- SK Návod na použitie

Attaching the handlebar

The handlebar with brake lever is attached to the rear frame with a brake cable. To install the handlebar, all you need do is attach it correctly to the stem.

1. Place the handlebar in the stem so that the centre of the handlebar is in the centre of the stem. The brake lever must be positioned so that the child can brake with their right hand.
2. Use the Allen key supplied to attach the stem faceplate to the stem with the bolts provided.
3. Make sure that the bolts are securely tightened and that the handlebar is gripped firmly in the stem so that it does not move or twist in any way.



Attaching the saddle

1. Fit the seatpost clamp to the top of the seat tube.
2. Insert the seatpost through the clamp into the frame.
3. Gently tighten the bolt on the clamp, then close the clamp lever to secure the seatpost in the frame so that the seatpost holds firm and does not move or twist in the frame.
4. If the seatpost is loose in the clamp, release the clamp lever and repeat the procedure in point 3.
5. Repeat the steps above until you are sure that the seatpost is properly secured in the frame.



Attaching the front wheel to the fork

1. Unscrew the nuts and lock washers from the wheel axle.
2. Insert the wheel so that the wheel axle fits into the grooves in the fork.
3. Fit the lock washer so that the hook fits into the hole in the fork.
4. Screw on the nuts on both sides of the wheel.
5. Make sure the wheel holds firmly in the correct position and that it turns smoothly when you spin it.
6. Inflate the tyres to the pressure indicated on the side of the tyre.



Safety and riding instructions

1. Before starting off, make sure the saddle, wheels and handlebar are firmly and securely attached. Check that the brake is working. Incorrectly mounted or loose parts may cause an accident and injury!
2. We recommend that, for safety, your child always wear a helmet, elbow and knee pads, and gloves.
3. Children may only use the balance bike under adult supervision.
4. Children should hold the handlebar with both hands while riding. To get the bike moving, they push off with their feet (one at a time), and learn to balance.
5. To brake, press the brake lever on the handlebar. The distance between the lever and the handlebar can be adjusted by tightening/loosening the side screw. To bring the lever closer to the handlebar, tighten the screw.



6. Children brake/slow down naturally on the bike by dragging their feet on the ground, so when riding the bike they must always wear shoes with thick enough soles.
7. Only one person is allowed on the bike at a time.
8. The bike has a maximum carrying capacity of 30 kg.
9. Use the bike in daylight in areas reserved for sports.
10. When ridden in reduced visibility and on roads, the bike must be fitted with safety features (lights, reflectors) in accordance with applicable regulations.

Maintenance

Proper maintenance will prolong the life of the bike and increase its safety.

1. Regularly check that all bolts are tight.
2. Lubricate the brake lever bearings and pins, and the brake cable.
3. Do not get grease on the rims or brake pads. If they become dirty, degrease them with a suitable product.
4. Check the spokes and spoke nipples.
5. Store the bike in a dry, shady place.
6. Inflate the tyres to maximum pressure (indicated on the side of the tyre) before winterising the bike.
7. Worn or damaged parts must be replaced immediately.
8. The manufacturer is not responsible for damage caused by improper maintenance.

Warranty policy

The first owner has a 24-month warranty on the balance bike and components as of the date of purchase. During the warranty period, the manufacturer will fix, at its own expense, any faults in the product caused by defective materials or workmanship, or by incorrect assembly on the part of the manufacturer. After the warranty period has expired, the customer is responsible for any repairs, new replacement parts, labour, and shipping or postage associated with such repairs. Frame and component warranties do not cover defects caused by the owner, failure to follow instructions, wear and tear, or use for purposes for which the balance bike and components are not intended. The manufacturer assumes no responsibility for injuries sustained in the use of the bike.

Warranty

With a balance bike, the warranty usually covers any defect that can be remedied by repair or replacement of the defective part, not by the replacement or return of the entire product. These repairs ensure that the customer can continue to use the product properly.

Terms of warranty:

- The bike may only be used for the purpose for which it has been designed
- When exercising the warranty, please present the bike complete and clean
- When exercising the warranty, please submit a confirmed and completed warranty certificate or proof of purchase
- If damage to the product is caused not by the manufacturer, but by the user (unqualified intervention, extreme and improper for use, lack of maintenance, poor storage, etc.), the warranty is void.

Warranty on individual parts

Frame and handlebar

The warranty covers manufacturing and material defects. The warranty does not cover damage caused by falls, collisions or abrasion. If the original paintwork is removed or painted over, the warranty on the frame or fork is void.

The warranty covers a cracked axle or rim. A cracked tyre, damage to the rim caused by any form of collision, and tyre overinflation are not covered by the warranty.

The warranty does not cover

- Fair wear and tear
- Bowden and other cables, grips or plastic parts
- Defects caused by incorrect handling and maintenance
- Defects caused by the user

Exclusion of liability

Pells Distribution s.r.o. is not liable for damage to property, the cost of borrowing or hiring equipment, travel costs, loss of earnings, etc. Liability is limited to the cost of the product. This warranty is without prejudice to the buyer's rights under applicable national laws, i.e. the buyer's rights in relation to the seller under the contract of sale and other rights. This warranty is the buyer's sole and exclusive remedy, and Pells Distribution s.r.o. assumes no incidental or consequential liability for incidental or consequential damage or breach of statutory or contractual warranty obligations relating to this product. The warranty does not apply if defects other than defects in materials and workmanship are found.

WARRANTY CERTIFICATE

SELLER		PURCHASER	
Stamp and signature		Name	
		Address	
Date of sale		Contact	

pells

Pells Distribution s.r.o.

Průmyslová 894
747 23 Bolatice
Czech republic